

Panasonic	INSTRUCTION MANUAL									
Universal Sensor Mounting Stand										
Horizontal mouting ty	pe Vertical mounting type									
MS-AJ1□	MS-AJ2□									
	MJE-MSAJ1 No.0035-06V									

Thank you very much for purchasing Panasonic products. Please read this Instruction Manual carefully and thoroughly for the correct and optimum use of this product. Kindly keep this manual in a convenient place for quick reference

5 DIMENSIONS (Unit: mm)





Material: Stainless steel (SUS304)

• This product can fix CX-400 series, EQ-20 series, EX-40 series, reflectors (RF-210, RF-220, and RF-230), and fibers (FD-L51, FD-L52, FD-L53, FD-L54, and M3/M4/M6 threaded head fiber) at any angle or position.

OUTLINE

• Two types of the mounting stand, MS-AJ1 which can be mounted on a horizontal surface and MS-AJ2 which can be mounted on a vertical surface, are available


2 PART COMPOSITION

	Туре	Assembly sets			Components									
No.	Model No.	MS-AJ1 MS-AJ2 Basic assembly	Lateral arm	MS-AJ1-M MS-AJ2-M Assembly for reflector	Assembly	MS-AJS Sensor mounting unit	MS-AJR Reflector mounting unit	MS-AJ-R1 Reflector mounting bracket	MS-AJD Fiber mounting unit	MS-FD-1 Fiber mounting bracket	MS-AJL Arm joint unit	MS-AJ1B MS-AJ2B (Base unit)	MS-AJG (Cable guide)	MS-AJP [Arm (Pipe)]
1	Base for horizontal mounting (Accessory for MS-AJ1)	1	1	1	1	_	-	—	_	-	—	1	-	—
2	Base for vertical mounting (Accessory for MS-AJ2	1	1	1	1	-	-	-	-	-	-	1	-	-
3	Arm (Pipe)	1	2	1	2	-	-	-		-	-	-	-	1
4	Attachment	1	1	1	1	1	1	-	1	-	-	-	-	-
5	Sensor mounting bracket	1	1	-	-	1	-	-	-	-	-	-	-	-
6	Cable guide	1	2	-	2	-	-	-		-	-	-	1	-
\bigcirc	Arm joint	-	1	-	1	-	-	-	-	-	1	-	-	-
8	M4 (length 12mm) hexagon-socket-head bolt (Drilube applied product)	1	3	1	3	1	1	-	1	-	2	-	-	-
9	M4 (length 15mm) hexagon-socket-head bolt (Drilube applied product)	1	1	1	1	-	-	-	-	-	-	1	-	-
10	M4 (length 22mm) hexagon-socket-head bolt	1	1	1	1	1	1	-	1	-	-	-	-	-
1	M4 nut	3	5	3	5	2	2	-	2	-	2	1	-	-
12	M4 spring washer	1	1	1	1	1	1	-	1	-	-	-	-	-
13	M4 flat washer	1	1	1	1	1	1	-	1	-	-	-	-	-
14	M3 (length 14mm) screw with washers for CX-400 series	2	2	-	-	2	-	-	-	-	-	-	-	-
15	M3 (length 18mm) screw with washers for EQ-20 series	2	2	-	-	2	-	-	-	-	-	-	-	-
16	Auxiliary mounting plate for EQ-20 series	1	1	-	-	1	-	-	-	-	-	-	-	-
\bigcirc	M3 (length 16mm) screw with washers for EX-40 series	2	2	-	-	2	-	-	-	-	-	-	-	-
18	Auxiliary mounting plate for EX-40 series	1	1	-	-	1	-	-	-	-	-	-	-	-
19	Reflector mounting bracket	-	-	1	-	-	1	1	-	-	-	-	-	-
0	M3 (length 8mm) screw with washers for RF-220	-	-	2	-	-	2	2	-	-	-	-	-	-
2	M4 (length 8mm) screw with washers for RF-230	-	-	2	-	-	2	2	-	-	-	-	-	_
22	Fiber mounting bracket	-	-	-	1	-	-	-	1	1	-	-	-	-

Note: The numbers shown in the table adove indicate the quantities of the respective parts.

3 ASSEMBLY

Assembly diagram



Note: The assembly for reflector (**MS-AJ-M**) does not contain the **(6)** cable quide

The MS-AJ1-F, MS-AJ2-F (assembly for fiber) includes parts enclosed by the dotted line in place of the 5 sensor mounting bracket. (e.g.: FD-L51)

MS-AJ1-A, MS-AJ2-A, MS-AJ1-F, MS-AJ2-F

e.g.: CX-400 serie


The base of **MS-AJ2**


differs.

• Mounting example

· The below figure shows the CX-400 series on









T

4 CAUTIONS

- The tightening torque of the attached M4 hexagon-socket-head bolts (8), 9), and 10 in SESEMBLY) should be 1.2N m or less.
- To mount the stand on your equipment, use M6 screws. The tightening torque should be 2N m or less.
- (Please arrange the M6 screws separately.) Take care that if excessive torque is applied, the products may get damaged.
- When using the stand, take care that excess vibration is not applied to the sensor.
- Do not apply excess stress on any part of the stand.
- Do not thread the fiber cable into the pipe when the fiber head is mounted on MS-AJ1-F, MS-AJ2-F.
- Refer to the instruction manual attached to each product for details of CX-400 series, EQ-20 series, EX-40 series or fibers.








Two M3 (length 14mm) screws with washers, two M3 (length 16mm) screws with washers, two M3 (length 18mm) screws with washers, one auxiliary mounting plate for EQ-20 series and one auxiliary mounting plate for EX-40 series are attached.

- Notes: 1) The dimensions in the brackets indicate the adjustable range of the movable part.
 - 2) Refer to MS-AJ1, MS-AJ2 (basic assembly) for the assembly diagram with the base or sensor mounting bracket.
 - 3) This value is 210mm for MS-AJ2-A.
 - 4) This value is 36.5mm for MS-AJ2-A.
 - 5) This value is 208.5mm for MS-AJ2-A



washers and two M4 (length 8mm) screws with washers are attached.

- Notes: 1) The dimensions in the brackets indicate the adjustable range of the movable part.
 - 2) Refer to MS-AJ1, MS-AJ2 (basic assembly) for the assembly diagram with the base.
 - This value is 143.5mm for MS-AJ2-M This value is 200mm for MS-AJ2-M. This value is 40mm for MS-AJ2-M.

Panasonic Industrial Devices SUNX Co., Ltd.

http://panasonic.net/id/pidsx/global **Overseas Sales Division (Head Office)** 2431-1 Ushiyama-cho, Kasugai-shi, Aichi, 486-0901, Japan Phone: +81-568-33-7861 FAX: +81-568-33-8591 About our sale network, please visit our website

• MS-AJ1-M, MS-AJ2-M (Assembly for reflector)